

Ground Connection Tap

For better bench-top organization.



User-friendly design

- * Twin connecting terminals provide a desktop ESD mat with earth connection when used with the optional Vessel Mat Connection Gel.
- * Ground Connection Tap provides a desktop ESD mat with earth connection when it is attached to the surface of the mat with optional VESSEL Mat Connection Gel.
- * Optimum 1MΩelectrical resistance installed in Ground Connection Tap.
- * Grounding wire is equipped with a round-shaped end terminal optimal for various kinds of grounding and installation.






Ground Connection Tap


APPLICATION

This unit provides an intermediary link for ESD wrist straps and rubber mats to be connected with the grounding wire. Attach it to the top or side of a workbench.

*Attached to VESSEL Mat Connection Gel (w/ snap-stud terminal), this unit works as a grounding connection of the ESD mats.








* Installation to tha side / reverse side of the workbench

SPECIFICATIONS

Product name	Ground Connection Tap
Product No.	EPS-GT2
Grounding wire	Approx. 3 m w/ round end terminal
Electrical resistance	approx. 1MΩ between the earth connection jack and round terminal
Material	Housing material: ABS resin Snap-stud terminal: stainless steel
Inner carton quantity	20

DIMENSIONS (mm)



***VESSEL Wrist Ground Sensor Series easily connects** to this Ground Connection Tap with banana plugs.

-CILVIA Banana plug

ESD-related products



Mat Connection Gel (Optional Parts)



Ground Sensor

EPS-01

EPS-01G

For ESD protected areas (EPA) For general use



Ground Cord EPC-18(1.8m) / EPC-30(3.0m)




Wrist strap sensor for the use in cleanrooms

Metal Band Ground Sensor EPS-02M / S (Metal Band) **EPS-03M/S**

Optimum for the use

in cleanrooms



Conductive Rubber Mat SG-100 / LG-100(10m) SG-50 / LG-50 (5m) SG-20 / LG-20 (2m)



ESD Solution Wrist Strap (20 sets included, economy package) **EPS-04**

*For further information, please contact us.

A CAUTION

* Ensure stable earth connection by properly attaching the grounding wire* Ensure the ground cord plug of Wrist Ground Sensor is properly inserted in the earth connection jack. * Hold the unit firmly when pulling out the banana plug. * Use this product only for its intended purposes. * Do not touch the power-supply module although it is designed to provide $1M\Omega$ electrical resistance.

Manufactured by

VESSEL CO., INC.

17-25, Fukae-Kita 2-chome, Higashinari-ku, Osaka 537-0001 Japan

Tel: +81 6 6976 7778 Fax: +81 6 6972 9441

E-mail: export@vessel.co.jp URL: http://www.vessel.jp

Distributed by:

08120133.15 Printed in Japan